



EDGE-SUPPORTED SAFETY SHIELD INSTALLATION INSTRUCTIONS


EDGE-SUPPORTED SHIELD KIT

The Edge-Supported Shield utilizes a U-Channel for support, and does not require vertical posts. This system provides a solid barrier with no gaps. Customizable lengths up to 20'. The aluminum U-Channel works with a variety of infill materials and accommodates thicknesses from 3/8" to 1/2". Multiple finishes and claddings are available.


KIT INCLUDES (Part #A54-5040)



(1pc) TOWERTECH2 CLEAR ARCHITECTURAL SEALANT
Part #: G42-5950CLR



(1pc) GLAZING GASKET
Part #: V50-0601BKA



(1pc) ALUMINUM U-CHANNEL
Part #: A40-1402BSA10


OR



(1pc) LOW PROFILE BASE CHANNEL
Part #: A42-0064AEY10C

Recommended: 1/4 in. x 1-1/4 in. Lag Screw

Recommended: 1/4 in. x 2 in. Lag Screw



OPTIONAL END CAP:



(2pc) END CAP
Part #: A17-1402BSA


OR



(2pc) END CAP
Part #: A17-0064

NOTE: For use with Part #: A40-1402BSA10 Only

NOTE: For use with Part #: A42-0064AEY10C Only






INSTALLATION

The following information will help you streamline set-up and installation.

1

On the bottom of the inside of the U-Channel, mark and drill the screw holes to the specifications shown in the diagram below.



2

Attach the U-Channel to the substrate: Set the U-Channel on the substrate in the final installation position. Mark the pilot hole positions using the drilled screw holes in the bottom of the U-Channel. Remove the U-Channel from the substrate. Drill the marked pilot holes. Place the U-Channel back on substrate and drive the screws into place.

3

Apply the Sealant to the entire length of the inside of the U-Channel.
NOTE: Ensure that all of the screws are covered with the Sealant.




4

Place the Infill inside of the U-Channel.

5


Place the Gasket along the U-Channel on both sides of the infill.






6

Apply Sealant to the U-Channel and attach the Endcaps.



Final installed U-Channel



For additional support call 800.325.7513 or visit our website www.morseindustries.com



Northwest Distribution Facility
Morse Industries Headquarters
25811 74th Avenue South
Kent, WA 98032

Southwest Distribution Facility
Morse Industries
3080 Enterprise Avenue, Suite A
Brea, CA 92821

Central U.S. Distribution Facility
Morse Industries
4041 N. Santa Fe Ave.
Oklahoma City, OK 73118

Mid-Atlantic Distribution Facility
Morse Industries
1630 Old Dunbar Road
West Columbia, SC 29172